


HOW TO MEASURE YOUR POLES



There are two measurements required to know if you are purchasing accessories.

The first measurement is the Outer Edge to Outer Edge Pole Diameter measured across the top of the pole in inches. This measurement is required when purchasing accessories that fit outside the pole such as:

- **Swing Brackets**
- **U Handles**
- **Tapered Locks**
- **Side Bars with Hooks**
- **Shelving**

When purchasing accessories that fit inside the poles you will also need to know the pole thickness. The thickness is measured with a caliper on the smooth end of the pole in milliliters. These accessories include:

- **Pole Connectors**
- **Screw In Inserts**
- **Push In inserts**

If you have any further questions please call us at 866-375-7994